


Keyboard and Mouse Adapter




How to Use:


1. Insert the adapter into the usb port of the Windows PC.
2. Open the software and select the mode (Xbox One, Nintendo Switch, PS4, PS3).
3. The mouse sensitivity value is between 4 ~ 23, the Turbo value is between 0 ~ 4, and 0 stands for off.
4. About Key Mapping: the default optimization of the keys have been made for the gun battle games. If some keys are occupied during the setting process, please leave the occupied button to continue setting.
5. After the setting is completed, click the Save button in the upper right corner. When the interface pops up "Write Successful!", it means that the save is successful, then close the software.
6. When using on Nintendo Switch and PS3, press "Ctrl + 1" on the keyboard as the PS3 mode and press "Ctrl + 2" as the Nintendo Switch mode.
7. Under normal use, press "Ctrl + Esc" on keyboard to restore the default key mapping of the corresponding mode. For example, pressing "Ctrl + Esc" on PS4 mode can only restore the default keys on PS4. Settings by other modes will not restore the default.
8. This software only supports Windows 2000 ~ Windows 10, Apple and Android systems are not supported at this time.

Please note: the software is currently only supported on Windows systems.


Software loadload link : https://www.sparkfox.cn/downloads/pro_kam_software.zip




Software Main Interface




Advanced Key Mapping Setting for Xbox One




Advanced Key Mapping Setting for PS4



Advanced Key Mapping Setting for Nintendo Switch



Advanced Key Mapping Setting for PS3



Advanced Key Mapping Setting for Xbox One



Advanced TURBO

L1	K	Q	TURBO	<input type="checkbox"/>
R1	K	E	TURBO	<input type="checkbox"/>
L2	M	M Right	TURBO	<input type="checkbox"/>
R2	M	M Left	TURBO	<input type="checkbox"/>
×	K	Space	TURBO	<input type="checkbox"/>
○	K	C	TURBO	<input type="checkbox"/>
□	K	F	TURBO	<input type="checkbox"/>
△	K	R	TURBO	<input type="checkbox"/>
L3	K	LShift	TURBO	<input type="checkbox"/>
R3	K	M	TURBO	<input type="checkbox"/>

Advanced Key Mapping Setting for PS4



Advanced TURBO

L **K** **Q** TURBO

R **K** **E** TURBO

ZL **M** **M Right** TURBO

ZR **M** **M Left** TURBO

A **K** **Space** TURBO

B **K** **C** TURBO


X **K** **F** TURBO

Y **K** **R** TURBO

L3 **K** **LShift** TURBO

R3 **K** **M** TURBO

Advanced Key Mapping Setting for Nintendo Switch



Advanced Key Mapping Setting for PS3